





CRF 250 L Uyumlu Motor Alt Koruma 2013-2020 • CRF 250 L Compatible Crankcase Guard 2013-2020

No	Adet • Qty.	Parça • Parts
A	2 x	 (M6x40 Bombeli Başlı Cıvata) (M6x40 Bolt)
B	2 x	 (25 cm Sünger Bant) (25 cm Sponge Tape)

Gerekli Aletler • Required Tools

 (10mm Lokma Anahtar) • (10mm Socket Key)

 (4 Alyan) • (#4 Allen)

Montaj Talimatları

- 1- Aşama 1'de gösterilen motosikletinizin orijinal alt koruma kapağını 10mm lokma yardımıyla cıvatalarını sökerek çıkartın.
- 2- Paket içeriğinden çıkan sünger bantı aşama 2'de gösterildiği gibi yapıştırın.
- 3- Alt koruma demirini motosikletinizden çıkardığınız orijinal koruma kapağının yuvasına takın. Taktıktan sonra öndeki cıvata yuvalarından 6x40 bombe başlı cıvata ile 4 alyan yardımıyla cıvatalayın.

Mounting Instructions

- 1- Remove the original lower guard cover of your motorcycle shown in Stage 1 by removing the bolts using a 10mm socket key.
- 2- Paste the sponge tape from the package as shown in step 2.
- 3- Attach the protection bar to the slot of the original protection cover you removed from your motorcycle. After installation, bolt the bolt holes in the front with the help of 6x40 bolts and 4 allens.

