






No	Adet	Parça
A	2 x	 (Egzoz Koruma Takoğu) (Exhaust Guard Wedge)
B	2 x	 (Egzoz Koruma Takoğu Kapağı) (Exhaust Guard Wedge Cover)
C	2 x	 (M10 x 100 Anahtar Başlı Civata) (M10 x 100 Bolt)
D	2 x	 (GP Kompozit Sticker)

Gerekli Aletler • Required Tools



(10mm Lokma Anahtar) • (10mm Socket Key)



(10mm Lokma Anahtar) • (10mm Socket Key)

Montaj Talimatları

- 1- Motosikletinizin egzozunun altında bulunan 2 adet kendinden pullu anahtar başlı civataları 1. görselde gösterildiği gibi sökün.
- 2- Söktüğünüz civata yuvalarına egzoz koruma takozlarını (A) koyun ve üzerinden M10x100 civataları (C) takın.
- 3- Aşama 3'te gösterildiği gibi takoz kapaklarını takozların üstüne takın.
- 4- GP Kompozit stickerlarını takoz kapaklarının üstlerine istediğiniz doğrultusunda yapıştırın.

Mounting Instructions

- 1- Remove the 2 bolts with #17 1/2 wrench located under the exhaust of your motorcycle as shown in the 1st image.
- 2- Put the exhaust protection wedges (A) in the bolt slots you removed and screw M10x100 bolts (C).
- 3- Screw the wedge covers over the wedges as shown in step 3.
- 4- Stick the GP Kompozit stickers on the top of the wedge covers as you wish.

