




PCX 125-150 Uyumlu Ön Cam 2014-2017 • PCX 125-150 Compatible Windscreen 2014-2017

No	Adet • Qty.	Parça • Parts
★	4 x	(Orijinal civatalar) • (Original Bolts)

Gerekli Aletler • Required Tools


(Yıldız Tornavida) • (Star Screwdriver)


(4 Alyan) • (#4 Allen)


(10mm Lokma Anahtar) • (10mm Socket Key)

Montaj Talimatları

- 1- Aşama 1'de gösterilen v parça ön siperliğin vidalarını yıldız tornavida yardımıyla şekilde gösterildiği gibi sökün.
- 2- Aşama 2'de gösterilen v parça ön siperlik ucundan düz tornavida yardımıyla ön siperliği trnağından ayırın.
- 3- Aşama 3'te gösterildiği şekilde v parça ön siperliği aşağıya doğru çekerek çıkarın sonrasında motosikletinizin orijinal camının alt civatalarını 5 alyan üst civatalarını ise 10mm lokma anahtar yardımıyla sökün.
- 4- Aşama 4'te gösterilen vida yuvalarına spor camınızı oturtun.
- 5- Orijinal civatalarla camı monte ediniz.

Mounting Instructions

- 1- Unscrew the screws of the v-piece front shield shown in Step 1 with the help of a star screwdriver as shown in the figure.
- 2- Separate the front shield from its tab with the help of a flat screwdriver as shown in Step 2.
- 3- Remove the v-piece front shield by pulling it downwards as shown in Step 3, then remove the below bolts of the original windscreen of your motorcycle with 5 allen and a 10mm socket key.
- 4- Fit your sports windscreen into the screw slots as shown in Step 4.
- 5- Install the windscreen with the original bolts.

