





No	Adet Qty.	Parça • Parts	No	Adet Qty.	Parça • Parts
A	1 x	 (Sissy Bar)	C	2 x	 (M8 Pul)
B	2 x	 (8x50 Anahtar Başlı Vida)	D	2 x	 (16,5 boy 9 çap Burç)

### Gerekli Aletler • Required Tools



(13 Numara Yarım Anahtar) • (#13 1/2 Wrench)

### Montaj Talimatları

- 1- Motosikletinizin selesini açın daha sonrasında kuyruk kapağını sökebilmek için aşama 1'de gösterilen plastik kliplerin ortasına basın daha sonrasında onları çıkarın.
- 2- Kuyruk kapağını aşağıya doğru çekerek çıkarın.
- 3- Aşama 3'te gösterilen deliklere burçları ekleyin.
- 4- Aşama 4'te gösterildiği şekilde sissy barı burçların üzerine denk gelecek şekilde koyun.
- 5- Aşama 5'te gösterildiği gibi sissy bar bağlantı demirinin üstüne sırasıyla pul ve civatayı monte edin.

### Mounting Instructions

- 1- Open the seat of your motorcycle, then press the middle of the plastic clips shown in step 1 for removing the tail cover, then remove them.
- 2- Remove the tail cover by pulling it downwards.
- 3- Add bushings to the holes shown in Step 3.
- 4- Put the sissy bar on the bushings as shown in step 4.
- 5- Mount the flake and bolt respectively on the sissy bar anchor as shown in step 5.

