




No	Adet • Amount	Parça • Parts
A	4 x	(M5x20 Pul Başlı Cıvata) (Wedge)
B	4 x	(20 Dış-6,5 İç Çap Conta) (Dia 20x6,5 Gasket)
C	4 x	(M5 Conta) (M5 Gasket)
D	4 x	(M5 Somun) (M10x100 Bolts)
E	4 x	(M5 Pul) (M5 Flake)

Gerekli Aletler • Required Tools



Montaj Talimatları

- 1- Aşama 1'de gösterildiği gibi aynayı tutan cıvata-ı 14 anahtar yardımıyla açın.
- 2- Aşama 2'de gösterildiği gibi aynayı çıkartın.
- 3- Aşama 3'te gösterildiği gibi elcik korumanın bağlantı parçasını ayna ile manşonun arasına yerleştirin.
- 4- Aşama 4'te gösterildiği gibi sırasıyla cıvata-M5 conta - elcik koruma - kalın conta - bağlantı demiri - pul ve somunu monte edin.

Mounting Instructions

- 1- Open the bolt holding the mirror as shown in step 1 with the help of 14 wrenches.
- 2- Take out the mirror as shown in step 2.
- 3- Place the fixing part of the handle guard between the mirror and the sleeve as shown in step 3.
- 4- Mount the bolt - M5 gasket - handle guard - thick gasket - fixing part - flake and nut respectively as shown in step 4

