



PAKET İÇERİĞİ: (Package Contents)

4 Adet m10x20x6 siyah kaplı pul
(4 pieces of M10x20x6 black-coated washers)

4 Adet m5x12 havşa başlı vida
(4 pieces of M5x12 countersunk screws)

1 Adet 4cm norton bant
(1 piece of 4 cm Norton tape)

1 Adet Gp logolu ayak
(1 GP-logoed footrest)



Kullanılacak Takımlar: (Necessary Tools)

No:4 Alyan
(Number:4 Allen)

NOTE: Please do not proceed with the product assembly without reading the assembly instructions and important precautions included in the package!!

NOT:Lütfen paket içerisindeki montaj talimatlarını ve önemli uyarıları okumadan ürün montajına başlamayınız!!



Ayak genişletmenin tam ortasına norton bandı yapıştırınız.
(Stick the Norton tape in the exact center of the footrest extension.)



Ayak genişletmeyi motosikletin yan ayaklığına getirip yapıştırınız.
(Position the footrest extension on the motorcycle's side stand and attach it.)



İşaretlenen dört adet deliğe siyah kaplı pul Ayak genişletme tarafına gelecek şekilde Havşa başlı civatayla birleştirip Ayak genişletmeye montaj yapınız.

(Align the black-coated washers with the four marked holes so that they face the footrest extension, then secure them with the countersunk screws and mount the footrest extension.)