






Montaj Kılavuzu • Mounting Instructions

XMAX 250 Tech / Iron Max 2018-2022 Uyumlu Basamak Alüminyum • XMAX 250 Tech / Iron Max 2018-2022 Compatible Aluminum Foot Step

No	Adet • Qty.	Parça • Parts
A	2x	 (Alüminyum Basamak) (Aluminum Foot Step)
B	2x	 (Aparat) (Apparatus)

No	Adet • Qty.	Parça • Parts
C	4x	 (M6x35 Havşa B. Cıvata) (M6x35 Bolt)
D	8x	 (M6x12 Havşa B. Cıvata) (M6x12 Bolt)

Gerekli Aletler • Required Tools
 (4 Alyan) • (#4 Allen)

Montaj Talimatları

- 1- Aşama 1'de gösterildiği gibi motosikletinizin paspaslarını çıkarın.
- 2- Alüminyum basamağı aşama 2'de gösterildiği gibi bağlantı aparatına M6x12 havşa başlı cıvatalarla çok sıkmadan sabitleyin.
- 3- Birleştirdiğiniz parçaları söktüğünüz paspasların yuvalarına yerleştirin.
- 4- Şekilde gösterilen sunta vida yuvalarından yıldız tornavida yardımıyla alüminyum ayak basamağını paspas yuvasına monte edin. M6x35 havşa cıvataları ise yine şekil 4'te gösterilen yuvalardan 4 alyan yardımıyla monte edin.

Mounting Instructions

- 1- Remove your motorcycle's mats as shown in step 1.
- 2- Fix the aluminum step to the bracket with M6x12 countersunk bolts without tightening too much as shown in step 2.
- 3- Place the assembled parts into the slots of the mats you removed.
- 4- Assemble the aluminum foot step to the mop socket with the help of a Phillips screwdriver from the chipboard screw slots shown in the figure. Mount the M6x35 countersunk bolts with the help of 4 hex sockets from the slots shown in figure 4.

